

"WARNING" : DO NOT WATCH TV WHILE VEHICLE IS IN MOTION.
IT CAN BE DANGEROUS.

TFT 8.4 inch CEILING MOUNT MONITOR INSTRUCTION MANUAL



OPERATING INSTRUCTION

Before operating the units, please read this manual thoroughly and retain it for future reference.

OWNER'S RECORD

The model and serial numbers are located on the bottom.
Record the serial numbers in the place provided below.

CAUTION

Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

MODEL NO:

SERIAL NO:

Thank you for your selection of our new TFT LCD Monitor.
For perfect operation and security, read this manual carefully
and keep it for future reference.

CONTENTS

- 1. PRECAUTIONS**
- 2. FEATURES**
- 3. COMPOSITION**
- 4. MONITOR PARTS**
- 5. REMOTE CONTROL**
- 6. MOUNTING**
- 7. WIRING CONNECTION**
- 8. SPECIFICATIONS**
- 9. TROUBLESHOOTING GUIDE**

1. PRECAUTIONS

1. Operate the transmitter on 12V DC supply only.
2. Do not open the monitor
Open or removing covers may expose you to dangerous shock hazards or the risks.
3. Do not expose temperature extremes or direct sunlight.
4. Avoid dropping and hard impact.
5. The driver should not watch while driving vehicle.
6. Do not spill any liquid into the cabinet or use your monitor near water
7. Do not place this product on a slopping or unstable surface.
As the monitor may fall, causing serious damage to the monitor.
8. Do not scratch or press the surface of the LCD panel, it will cause a permanent damage.
Use only soft cloth with non-ammonia glass cleaner to clean the panel.

2. FEATURES


- Full fuction on-screen display(OSD)
- Two A/V inputs(composite AV1/AV2)
- High resolution:800x600
- NTSC/PAL switchable(auto-selection)
- Full function remote control
- Built in dual dome light with 2 switches.
- Built in IR transmitter(IR-Headphone)
- Filp-Down angle(0-115 degrees)
- Swivable(left, right 30)

3. COMPOSITION


- Your TFT LCD monitor box should contain the following:



TFT LCD Monitor



Remote Control



Metal Mount Bracket



Screws




AV Cable



Owner's manual




4. MONITOR PARTS





MENU

BRIGHTNESS
CONTRAST
SATURATION
HUE
SHARPNESS
VOLUME
MUTE

MIRROR
LANGUAGE
DISPLAY
INPUT SELECT
DEFAULT SETTING
EXIT


-  POWER (ON/OFF)
-  MUTE
-  RESET

5. REMOTE CONTROL OPERATION


- **Power:**Power ON/OFF button
- **Mute:**Sound ON/OFF
- **Menu:**Show OSD menu on the screen menu selection
- **Select Up(▲)**  Function up and down
- **Select Down(▼)**  Function up and down
- **Source:**Selection button for selecting Av1, Av2
- **Sound:**Show sound volume
- **Inversion:**Screen inversion(left, right)

6. MOUNTING PLATE

• IR & Dome Light Power Souce



7. WIRING CONNECTION



8. SPECIFICATIONS

POWER SUPPLY	DC 12Volt \pm 10%
SCREEN FORMAT	4:3 Ratio
SCREEN SIZE	8.4 inch
RESOLUTION	800(V)X600(H)
CURRENT CONSUMPTION	800ma
VIDEO FORM	NTSC/PAL
DIMENSION(mm)	210mmx207mmx30mm
WEIGHT	1kg

9. TROUBLESHOOTING GUIDE

Remote control unit doesn't work

- Batteries are missing, dead or incorrect polarity
Replace batteries
- Remote control distance is too far
The distance must be less than 5m
- Improper direction of remote control
Point the remote control unit to the sensor

No picture and sound

- A/V source connection is wrong
Check the A/V source power

IR sensor inoperative

- Verify that batteries in the remote are fresh
- Verify that remote eye is not obstructed
- Verify that the infrared transmitter is affixed over the sensor eye of the component to be controlled

Important Safety Instructions



CAUTION

- Please read through the "Owner's Manual" and "Setup Manual" to use the product properly and safely before it is operated. Installing this product in a place that is exposed to damp, wetness, steam, dust, or oily smoke, or where it can interfere with your driving your own car may cause an accident, fire, electric shock, or damage to it.
- Travel your own car in accordance with the real traffic regulation if the navigation system guides a route.



WARNING

- Avoid <Branch Registration, Volume Control> <TV Viewing, Radio Listening> during driving.

AV System

1. AV System is equipped with the protective circuit for safety during driving so that the driver cannot view TV or listen to radio. Be sure to connect the appropriate terminal of the main unit to the parking brake on the vehicle or attach parking sensor.
2. Looking at the display screen or performing complex manipulation to ensure safe driving may cause a traffic accident due to carelessness in the forward direction. When operating this system, the driver should pull up his own car in a safe place and then operate the system. There are some features which cannot be controlled during travelling.

Installation

1. There are some types of vehicle on which such equipment as main unit, option unit, antenna, and setup card cannot be installed. For details, contact the dealer from whom you purchased your system.
2. Wiring for the installation of such equipment should be provided properly in a place that does not interfere with driving or safety device such as airbags.
3. Wire the equipment properly according to "Setup Manual" supplied with the product. Otherwise, malfunction or damage may result. Warranty does not apply to such damage. If it is difficult to connect or install the equipment, contact your dealer. We do not take any responsibility for any damage caused by change or modification of the equipment.
4. Use power source for vehicle with fuse having power capacity for the system, heat resistance and weather resistance in compliance with "Owner's Manual" when connecting the equipment to the power source on the vehicle. Using power cable for other than vehicle may cause damage to the system.
5. All the equipment has been designed to use 12V battery power source for vehicle. The equipment should not be connected to 24V power source on recreational vehicles and trucks.

Please, Note Warranty card.

